# SIT789 – Robotics, Computer Vision and Speech Processing

## Credit Task 7.2: Speech enhancement

## **Objectives**

The objectives of this lab include:

- · Applying low-pass, high-pass and band-pass filters to remove noise from speech signals
- Enhancing speech quality using spectral subtraction
- Practising scipy.signal package

### **Tasks**

## 1. Filtering

In this section, we will practise low-pass, high-pass, and band-pass filters. You first need to download the dataset in the Resources supplied in OnTrack. This dataset includes clean speech clips (in CleanSignals), noisy speech clips (in NoisySignals) and noise clips that contain only noise (in Noise). The dataset also include different types of noise, e.g., background noise from train stations, babble noise. The clean and noisy audio clips are from the NOIZEUS dataset. The noise clips are from the MS-SNSD.

In this lab, we will use scipy.signal. We update scipy with the newest version by doing:

```
pip install --upgrade scipy
```

Depending on the permission you set on your computer, you may need to provide user option in your pip command, e.g.,

```
pip install --user --upgrade scipy
```

To get the update affected, you need to restart your computer.

Take the audio file sp01\_station\_sn5.wav in NoisySignal/Station as an example. You then load the audio file as follows.


```
import numpy as np
import matplotlib.pyplot as plt
import librosa
import librosa.display
import IPython.display as ipd

from pydub import AudioSegment
from pydub.utils import mediainfo
```

```
noisy_speech = AudioSegment.from_wav('NoisySignal/Station/sp01_station_sn5.wav')
noisy_s = noisy_speech.get_array_of_samples() # samples x(t)
noisy_f = noisy_speech.frame_rate # sampling rate f
```


#### We can visualise the signal noisy\_s in time domain using the following code

```
plt.figure(figsize = (15, 5))
plt.plot(noisy_s)
plt.xlabel('Samples')
plt.ylabel('Amplitude')
```



Now, we examine the signal in noisy\_s in frequency domain by plotting its spectrogram using the Fourier transform.

```
#range of frequencies of interest for speech signal.
#It can be any positive value, but should be a power of 2
freq range = 2048
#window size: the number of samples per frame. Each frame is of 30ms = 0.03 sec
win length = int(noisy f * 0.03)
#number of samples between two consecutive frames
hop length = int(win length / 2)
#windowing technique
window = 'hann'
noisy S = librosa.stft(np.float32(noisy s),
                       n fft = freq range,
                       \overline{window} = window,
                       hop length = hop length,
                       win length = win length)
plt.figure(figsize = (15, 5))
#convert the amplitude to decibels, just for illustration purpose
noisy_Sdb = librosa.amplitude_to_db(abs(noisy_S))
librosa.display.specshow(noisy_Sdb, #spectrogram
                        sr = noisy_f, #sampling rate
                        x axis = 'time', #label for horizontal axis
                        y axis = 'linear', #presentation scale
                        hop length = hop length) #hop length
```



Suppose that we want to remove frequencies higher than 1000Hz from noisy\_s. We define a cut-off frequency cutoff\_freq = 1000 and construct a Butterworth (low-pass) filter with this cut-off frequency as follows.


```
from scipy import signal
#order
order = 10
#sampling frequency
sampling_freq = noisy_f
#cut-off frequency. This can be an array if band-pass filter is used
#this must be within 0 and cutoff freq/2
cutoff freq = 1000
#filter type, e.g., 'lowpass', 'highpass', 'bandpass', 'bandstop'
filter type = 'lowpass'
#filter
h = signal.butter(N = order,
                  fs = sampling freq,
                  Wn = cutoff freq
                  btype = filter type,
                  analog = False,
                  output = 'sos')
```

Now, we apply the filter h to noisy signal noisy\_s as follows.

```
filtered_s = signal.sosfilt(h, noisy_s)
```

filtered s is the filtering result of noisy s. You will need to save filtered s to file and auditorily evaluate its quality.

To visualise the effect of the filter h, we show the spectrogram of filtered\_s (using the same manner as what we have done to show the spectrogram of noisy\_s).



You should test this filter with the supplied speech data. You should also vary parameters used in the filter, e.g., order, cutoff\_freq, and manually inspect the corresponding filtering results.

Your tasks here include:

- 1. Implement a high-pass filter with a cut-off frequency = 200Hz using Butterworth filter. You can use the same parameter settings used in the previous low-pass filter. **Hint:** In signal.butter, set Wn = 200, btype = 'highpass'.
- 2. Implement a band-pass filter with a pass band = [200Hz, 1000Hz] using Butterworth filter. You can use the same parameter settings used in the previous low-pass filter. **Hint:** In signal.butter, set Wn = [200, 1000], btype = 'bandpass'.

#### 2. Noise attenuation

In this section, we will apply the spectral subtraction for noise attenuation. We will use the noisy speech data in the NoisySignals folder and the noise signals (of different noise types) in the Noise folder. The noisy speech data is organised into different sub-folders corresponding to their noise types, e.g., background noise from train stations, babble noise. Clean signals are also provided for evaluation of the noise attenuation algorithms.

Take the audio file  $sp01\_station\_sn5.wav$  in NoisySignal/Station as an example. Let y be the speech signal contained in  $sp01\_station\_sn5.wav$ , Y be the Fourier transforms of y, and  $mag\_Y$  be the magnitude of Y (i.e.,  $mag\_Y = abs(Y)$ ).

Similarly, let d be the noise signal contained in Noise/Station/Station\_1.wav. Let D be the Fourier transforms of d, and square\_mag\_D be the square of the magnitude of D. You are to implement d, D, and square\_mag\_D.

Note: in this example, we are working on "station" noise. Therefore, Noise/Station/Station\_1.wav is used. For other noise types, proper noise data should be used.

Note that square\_mag\_D is an array whose rows represent frequencies and columns represent temporal frames. Next, we calculate the means for rows in square\_mag\_D, i.e., averaged-time frequencies, (see Eq (17), slide 63 in week 7 lecture slides).

```
means square mag D = np.mean(square mag D, axis = 1)
```

#### Your tasks include:

- 1. Implement d, D, and square\_mag\_D
- 2. Implement the Fourier transform H (see Eq (19), slide 64 in week 7 slides)
- 3. Estimate the Fourier transform S\_hat (see Eq (20), slide 64 in week 7 slides)
- 4. Get the inverse of S\_hat to retrieve s\_hat, then save s\_hat to file named sp01\_station\_sn5\_spectralsubtraction.wav
- 5. Auditorily inspect the quality of sp01 station sn5 spectralsubtraction.wav
- 6. Visualise the spectrogram of sp01\_station\_sn5\_spectralsubtraction.wav, i.e., S\_hat, and the spectrogram of the clean signal in CleanSignal/sp01.wav
- 7. Test the spectral subtraction algorithm on the supplied speech signals in NoisySignal, provide observations and draw conclusions. Note that, you should not expect outstanding performance in noise reduction by the spectral subtraction algorithm.

#### Hint:

- 1. H, and S\_hat are 2D arrays and have the same shape with Y (i.e., same number of rows and same number of columns).
- 2. Use librosa.istft to calculate s hat (the inverse DFT of S hat) as follows.

3. s\_hat, computed using librosa.istft, may contain values out of the range of 16 bits. In order to store s hat in a 16-bit wave file, you need to truncate the value of s hat as follows.

```
s_hat_truncated = np.int16(s_hat)
for i, num in enumerate(s_hat_truncated):
    if num > 32767:
        s_hat_truncated[i] = 32767
elif num < -32768:
        s hat truncated[i] = -32768</pre>
```

Finally, you need to set parameter data in pydub. Audio Segment as:

```
data = array.array('h', s_hat_truncated)
```

## **Submission instructions**

- 1. Perform tasks required in Section 1 and 2.
- 2. Complete the supplied answer sheet with required results
- 3. Submit the answer sheet (.pdf) and code (.py) to OnTrack.